




# ECO-Series

## Installation Instructions for Tempo Submersible Pond Filters



Position your Tempo submersible filter in the deepest part of your pond, as far away from your waterfall as possible. We recommend using the Eco-Series universal waterfall diffuser or the Eco-Series waterfall spillways to help you create a beautiful, leak proof waterfall.

**Filters ponds up to 600 gallons!**



The Tempo filter is a heavy duty submersible filter that is great for water gardens up to 600 gallons total capacity. The filter provides mechanical and biological filtration.

## INSTALLING TEMPO FILTER

---



Place pump in bottom chamber of filter. We recommend EasyPro mag drive pumps up to 850 GPH.



Thread electrical cord through hole in base of filter. Always plug pumps into a GFI outlet.



Slide tubing through big hole in base of filter. Use 1/2" to 1" tubing.



Insert the white inner media.



Replace the black top pad.



Place filter in lowest part of pond, opposite the waterfall for best circulation.

## CLEANING TEMPO FILTER

---

1. Thoroughly rinse the top pad once a week or as needed depending on pond conditions.
2. Unroll and clean the inner pad monthly. Size of pond, fish load and other factors will determine exactly how often you will need to clean the filter.



800-448-3873 • Grant, Michigan  
www.EasyProPondProducts.com • info@EasyProPondProducts.com